



BX1850

2013-2018 Nissan 370Z Roadster/Coupe Installation Instructions

Attachment Tab Height: 13-1/2"

Attachment Tab Width: 23"

Serial Number

Please read BOTH these Installation Instructions and the General Instructions prior to installing or operating this equipment.

1. Blue Ox® towing products and accessories are intended to be installed by Blue Ox® Dealers who are familiar with our products and have the equipment and knowledge necessary to do "fit work". If needed, Blue Ox® Dealers can be found at www.blueox.com or by contacting our Customer Care Department at (402) 385-3051.
2. Many Blue Ox® baseplates are designed to use existing holes and hardware to mount the baseplate to the towed vehicle. Even though bolts are there, do not assume they are adequate for baseplate mounting. Always use the hardware supplied in the hardware kit and existing hardware as specified in the installation instructions.



If the front of your vehicle looks different than this, please contact us at (402)385-3051.

Reference your vehicle owner's manual for manufacturer's towing specifications.

Bolt Torque Specifications

Torque in Foot-Pounds for Inch Bolts

Bolt Size	Grade 5	Grade 8
1/4"	10	14
5/16"	19	29
3/8"	33	47
7/16"	54	78
1/2"	78	119
5/8"	154	230
3/4"	257	380

Bolt Torque Specifications

Torque in Foot-Pounds for Metric Bolts

Bolt Size	Grade 8.8	Grade 10.9
6MM	6	8
8MM	16	22
10MM	31	40
12MM	54	70
14MM	89	117
16MM	161	230
18MM	222	318



WARNING

Failure to read and follow these instructions could result in separation of the towed vehicle from the tow bar, causing property damage, loss of towed vehicle, personal injury or death.

BX1850
2013-2018 Nissan 370Z Roadster/Coupe
Installation Instructions

Instruction Notes: The fascia and windshield washer fluid reservoir are removed and reinstalled for the baseplate installation. Some drilling and trimming is required.

Place all components that are removed on a flat, sturdy surface. All items will be reinstalled unless otherwise noted after the baseplate is installed.

The dimensional variations between otherwise identical vehicles can be considerable. While the baseplate was designed for easy installation, it may be necessary to tailor the baseplate slightly to compensate for vehicle manufacturer's tolerances.

The BX8848 4-Diode Wiring Kit is recommended for this vehicle.

NOTICE

- Handling of some cosmetic parts when installing this product may require the use of protective covers, rags, specialty tools, etc. to prevent damage.
- When using power drills be aware of the dangers of torque and drill bit length.
- When using a reciprocating saw be aware of objects behind the cutting surface.
- Use a good quality paint to spray cut edges of frame to prevent rusting.
- Be sure that **ALL** electrical connections are plugged in and accessories are functioning properly before reinstalling the fascia.
- The baseplate is computer tested to your vehicle's GVWR, exceeding this weight will void the manufacturer's warranty.
- Be sure to use a sufficient amount of Loctite® Red on all bolt threads before tightening. Tighten all bolts according to the torque chart provided.
- Dealer or installer be certain the user receives these instruction sheets.
- If the baseplate is in an accident, it must be replaced. **DO NOT** use it again! An accident can cause unseen damage and using it again could result in more damage or serious injury. **DO NOT** use the baseplate if it is damaged or missing parts.


BX1850

2013-2018 Nissan 370Z Roadster/Coupe

Installation Instructions

Tools Required

Large Vise Grip
 Flat Screwdriver
 Utility Knife
 Torque Wrench
 Drill
 Tape Measure
 Loctite® RED
 13/32" Drill Bit
 1-1/4" Hole Saw
 10MM Socket
 12MM Socket
 14MM Socket
 14MM Wrench
 9/16" Socket



Item No.	Part No.	Description	Qty.
1.....	Existing.....	10MM Flange Bolt	2
2.....	61-4978	3/8"-16 Whiz Nut w/ 14" Wire	1
3.....	61-5208	3/8"-16 Nut Plate w/ 14" Wire	5
4.....	61-7342	BX1850 Baseplate.....	1
5.....	62-3468	Attachment Tab Assembly with Hole	2
6.....	102-7056	Breakaway Bracket	1
7.....	201-0050	1/4"-20 x 3/4" Hex Head Bolt, Grade 5, ZP	1
8.....	201-0192	#10-32 1/2" Round Slotted Head Screw.....	2
9.....	201-0368	3/8"-16 x 1-1/4" Hex Head Bolt, Grade 5, ZP	6
10.....	201-0654	#10-16 x 1" Self Drilling Screw, ZP	1
11.....	201-0979	#12-14 x 1" Self Drilling Screw, ZP.....	2
12.....	202-0047	#10-32 Hex Nut	2
13.....	202-0102	1/4"-20 Hex Nylon Nut, ZP	1
14.....	203-0003	3/8" Flat Washer, ZP.....	2
15.....	203-0010	3/8" Lock Washer, ZP	6
16.....	203-0054	#10 Lock Washer, ZP	2
17.....	299-0685	Electrical Bracket.....	1
18.....	226-0046(not shown)	Class III Safety Cables	2
19.....	229-0359(not shown)	3/8" Quicklink, ZP	2
20.....	290-0437(not shown)	Black Cap Plug Receiver.....	2

Important:

Use only genuine factory replacement parts on your baseplate. Do **NOT** substitute homemade or non-typical parts. If a bolt is lost or in need of replacement, for your safety and the preservation of your baseplate, be sure to use a replacement bolt of the same grade (In most cases it will be Grade 5, please reference the parts list above). Replacement parts may be ordered through your nearest Blue Ox® Dealer or Distributor. Failing to follow and/or altering these installation instructions in either installation or required equipment will void the manufacturer's warranty. Towing behind a non-motorized vehicle will void the warranty.


BX1850
2013-2018 Nissan 370Z Roadster/Coupe
Installation Instructions




1. Remove the seven (7) push pins from the top edge of the fascia.



2. Remove the push pin from the wheel well. Pull back the liner and using a 10MM socket, remove the screw the fascia joint (inset).




3. Using a 10MM socket, remove the ten (10) screws from the underside edge of the fascia. There are five (5) on each side of the vehicle.




4. Remove the plastic shielding from either side of the bumper. The shields will not be reinstalled.


BX1850
2013-2018 Nissan 370Z Roadster/Coupe
Installation Instructions



5. Using a 12MM socket, remove the eight (8) bolts from the bumper. There are four (4) on each side.




6. Using a 14MM socket and wrench, remove the two (2) bolts from the passenger side counterbalance and set aside it will not be reinstalled.



7. On the driver side, trim the plastic shielding back for baseplate clearance. Measure down 1" from the lip, back 1-3/4" and down 6".


Just below the notch, trim the corner off the lip as shown (inset).



8. On the passenger side, trim the plastic shielding back for baseplate clearance. Measure down 1" from the lip, back 1/2" and down 6".

Just below the notch, trim the corner off the lip as shown (inset).


BX1850
2013-2018 Nissan 370Z Roadster/Coupe
Installation Instructions




9. Using a 1-1/4" hole saw, drill an access hole on the outside of the frame on both sides of the vehicle.



10. Position the baseplate onto the vehicle. Start the two (2) existing bolts on the passenger side, level and clamp the baseplate to the frame. Fully tighten the existing bolts.



11. Using a 13/32" drill bit, drill a hole in the top front slot thru the frame on the driver side. Install a 3/8"-16 x 1-1/4" bolt with a 3/8" lock and flat washer and secure with a 3/8"-16 nut plate inside the frame. Fully tighten the bolt.



12. Using a 13/32" drill bit, drill a hole in the bottom front slot and rear hole thru the frame on the driver side. Install a 3/8"-16 x 1-1/4" bolt with a 3/8" lock and flat washer into the bottom slot and a 3/8"-16 x 1-1/4" bolt with 3/8" lock washer into the rear hole. Secure the bolts with a 3/8"-16 nut plates inside the frame. Continue drilling the front hole on the PS and underside holes. Install a 3/8"-16 x 1-1/4" bolts with a 3/8" lock washer into the holes. Secure the bolts with a 3/8"-16 nut plates inside the frame. Fully tighten all fasteners,

BX1850
2013-2018 Nissan 370Z Roadster/Coupe
Installation Instructions

13. Attach the permanent baseplate safety cables to the provided convenience link on the baseplate. Secure the cables to a solid piece of the frame as described in the instructions included with the permanent baseplate safety cables. Be sure the safety cables do not rub against any hoses or moving parts. Do this on **BOTH** sides of the vehicle.



14. Hold the fascia as close to its original position, mark and trim the fascia around the convenience links and attachment tabs. Reinstall the bumper and fascia.

CUSTOMER SERVICE COMMITMENT

Blue Ox® is committed to providing you with exceptional customer care throughout your lifetime with our products. Our team is here to assist you with any questions you may have regarding the performance of your product. Simply call (402) 385-3051 and you can speak with our customer care team.

Additionally, please visit our website to see which rallies our Destination America team will be attending. For a nominal fee, our service technician will service your towing system to ensure it's in proper working condition. Also, as a commitment to our customers, should you visit our factory, you can stay at our full service Blue Ox® campground at no charge along with enjoying a factory tour.

Again, thank you for being our customer and for the confidence you have shown in the performance of our products. It is because of customers like you we enjoy the success we have today.

© 2015 Blue Ox
One Mill Road, Industrial Park
Pender, Nebraska 68047
Phone: (402) 385-3051
Fax: (402) 385-3360
www.blueox.com

General Information

1. Ensure that your product(s) are registered online at www.blueox.com. It is crucial to register your product(s) so that you may be alerted of product offerings, updates, upgrades, maintenance and safety bulletins, and/or recalls.
2. **It is the owner's responsibility to inspect all towing equipment for cracked welds, missing or worn parts and loose bolts before each towing trip.** Be sure to use Loctite® Red on all bolts and tighten to the recommended specifications.
3. **It is the owner's responsibility to hook up all towing equipment per manufacturer's instructions/ recommendations.**
4. Remove the attachment tabs when not in use (if applicable).

Notice To Baseplate Installer

1. It is YOUR responsibility to watch for:

- Oil cooler and air conditioner lines
- Electrical wires and hoses
- Missing parts or attaching points on the frame

** If the baseplate is improperly installed and is against a wire or hose, it could cause fluid leaks or electrical shorts some time after the actual baseplate installation.


Permanent Baseplate Safety Cable Installation

Permanent baseplate safety cables are strongly recommended when towing a vehicle with a tow bar. The principle function of the permanent baseplate safety cables is to prevent the towed vehicle from breaking loose in the event the connection between the frame of the towed vehicle and the baseplate fails or becomes disconnected. The cables must be connected from the baseplate to the frame rail or cross member of the vehicle's frame. The illustrations below show the possible arrangements recommended by Blue Ox®. Each permanent baseplate safety cable must have an adequate weight rating for the towing system. The weight rating of the two (2) cables together will not qualify.

Do not mount the permanent baseplate safety cables against wires, hoses or brake lines.

These permanent baseplate safety cables should remain installed as long as the baseplate is installed on the vehicle. Permanent baseplate safety cables are to be used in conjunction with, and NOT a replacement for legally required safety cables attaching the towed vehicle to the towing vehicle.

OPTION #1



OPTION #2

